

## Boat Trim 6

For best boat and motor performance, the boat should be driven as nearly parallel to the water as possible. Driver and equipment should be so distributed in the boat that it is evenly balanced both front to rear and side to side.

**A**

**Incorrect**  
OVERLOAD FORWARD  
CAUSES BOAT  
TO "PLOW"

**B**


**Incorrect**  
OVERLOAD AFT  
CAUSES BOAT  
TO "SQUAT"

**C**

**Correct**  
BALANCED LOAD  
GIVES MAXIMUM  
PERFORMANCE



**Safety Warning: If engine is tilted forward so as to cause plowing (see A), swamping may occur in rough water. If engine is tilted aft so as to cause porpoising (see B), steering may be erratic or unstable. See correct angle adjustment (see C).**




**A**

DR1268



**B**

DR1269



**C**

DR1271